



## Electronica EL300 Display Reset

Congratulations on the purchase of your Electronica EL300 series kit. This article addresses how to reset your EL300 display.

Turn DRO off / then turn it back on.

< *push the SETUP button* >

EntEr

LoC

< *enter 35741 on the keypad* >

< *push the enter button* >

2 AXiS      1 AXiS / 2 AXiS / 3 AXiS < *press the #6 key to change values* >

< *push the #2 key* >

SimPLE      SimPLE / Edm / miLL / LAThE / SPECiAL < *press the #6 key to change values* >

< *push the #2 key* >

oPt oFF      oPt oFF / Opt on

< *push the #2 key* >

rSt dEF

< *push the enter button* >

**NOTE: The display will not react instantly.** Give the display time to react.

In a moment, it will read < in Prog > The reset will take several minutes to complete. When the reset is complete, the display will be back on the home ABS screen.