



Electronica EL400 Calculator Function

Congratulations on the purchase of your Electronica EL400 series display. This article addresses how to access the Calculator feature. This function allows the user to perform mathematical calculations.

Calculator Function:

1. To access the Calculator function, **push the Calculator button**. It's the bottom left-most button in the cluster of eight function buttons, and has a picture of a calculator on it. The x axis display window will immediately read "0", and the y axis window will be blank.

2. On the keypad, type in your desired value.

3. Push the "Y" button until the desired operation is selected. The available functions, in order, are as follows:

Add = add
SUb = subtract
nnULti = multiply
div = divide
Sin = sine
CoS = cosine
tAn = tangent
ASin = inverse sine
ACoS = inverse cosine
AtAn = inverse tangent

4. Push the "ent" button.

5. On the keypad, enter your desired second value, followed by the "ent" button.

6. The computed result is shown in the x axis display window.

7. Press the calculator button to exit out of the calculator function.

Congratulations, you've now accomplished the Calculator Function!

DRO PROS